

CLEANSPHERE™

The CleanSphere™ Hardwall/Softwall Cleanrooms feature our unique locking system, which enables quick and efficient on-site assembly
USP <797> AND <800>, OSHA, AND NIOSH COMPLIANT



CleanSphere™

PROTECTING LIFE
PROTÉGER LA VIE
PROTEGIENDO LA VIDA



**ASEPTIC
SAFE**

ISO Class 4-8 (Class 10-100,000) - Meets USP <797> and all other regulations

**ERGONOMIC
MODULAR
CLEAN**

Built according to your precise requirements

Hardwall/Softwall

Upgrade cleanliness levels quickly and easily

APPLICATIONS FOR SAFE PREPARATIONS

AIR FILTRATION

- > **FILTER** HEPA filter (99.99% DOP at 0.3 µm)

FEATURES

- > T-Bar cleanroom ceiling systems
- > Easy of cleanability
- > No recessed or sharp edges

TOTAL SOLUTION

- > Pre-painted white anti-microbial UL certified panels
- > Air-tight observation windows including a flush-mounted double panel with anti-humidity system
- > Light and durable doors with flush jambs (frames) which are ADA (American Disability Act) compliant

HARDWALL

- > Antimicrobial prepainted hardwall UL certified flush mounted airtight panels
- > Anodized aluminium framing system

SOFTWALL

- > Anodized aluminium or stainless steel construction
- > Strip anti-static curtains

INSTALLATION

- > The legs and ceiling members simply slide into our exclusive gusset sections and lock together
- > Once the frame and ceiling is assembled, simply place the HEPA Fan Filter units, ceiling lights and any ceiling tiles in the aluminium frame system
- > Attach the cleanroom curtains to the outer edge of the softwall frame and you're ready to go

OPTIONS

- > Antilock systems for doors
- > Pass through boxes
- > Monitoring and alarm panels
- > Shelving & cabinets cleanroom organizational systems

DELIVERY

- > 6-10 weeks

DOCUMENTATION & SERVICES

- > Operation and maintenance manual
- > S.O.P. (Standard Operational Procedure)

WARRANTY

- > 12 months